


NEW

cellcomprime

Slave Devices




NEW

cellcomprime

Slave Devices


Imperial Slave Keypad

PRIME-SLV-KP-IMP




- Imperial Slave Keypad.
- Works with any "PRIME-6" product.

PRIME-SLV-PX-IMP




- Imperial Slave Prox Reader.
- Works with any "PRIME-6" product.

PRIME-SLV-KP-AB



- Architectural Slave Keypad.
- Works with any "PRIME-6" product.

PRIME-SLV-PX-AB



- Architectural Slave Prox Reader.
- Works with any "PRIME-6" product.